


## DOMO 01-1030

### Zvončekové tlačítko



DOMO 01-1030-202 bi



|                     |              |                 |
|---------------------|--------------|-----------------|
| DOMO 01-1030-202 bi | <b>24716</b> | biela           |
| DOMO 01-1030-203 kr | <b>24776</b> | krémová         |
| DOMO 01-1030-243 sr | <b>24835</b> | strieborná      |
| DOMO 01-1030-241 gr | <b>24894</b> | grafit          |
| DOMO 01-1030-230 pe | <b>24953</b> | perleťovo biela |
| DOMO 01-1030-250 sz | <b>25012</b> | šampanská       |
| DOMO 01-1030-242 cm | <b>36473</b> | čierna matná    |

- Certifikát PZH: Číslo HK/K/1046/01/2017, platný do 20.12.2022
- Materiál: PC
- Plast: PC

## DOMO 01-1030

### Zvončekové tlačítko



DOMO 01-1030-202 bi



DOMO 01-1030-203 kr



DOMO 01-1030-243 sr



DOMO 01-1030-241 gr




DOMO 01-1030-230 pe




DOMO 01-1030-250 sz




DOMO 01-1030-242 cm




DOMO 01-1030-202 bi



DOMO 01-1030-203 kr



DOMO 01-1030-243 sr




DOMO 01-1030-241 gr


## DOMO 01-1030

---


### Zvončekové tlačítko



DOMO 01-1030-230 pe



DOMO 01-1030-250 sz



DOMO 01-1030-242 cm